

TARYAG

TLS-1 Tactical Green Laser

Package Includes:

- Laser device
- USB Charger and cable
- 1.5 mm hex wrench
- Instructions

Specifications

- Laser Wavelength: 532nm, Class III A
- Laser Power: <5 mw
- Laser working temperature: -5° F – +122° F
- Dot size @ 50 yds: 0.1 in.
- Visibility-day: 50 yds
- Visibility-night: 600 yds
- Battery: 3.7v 80mAh built-in, rechargeable
- Charging Voltage: 4.7V
- Laser runtime: ~2.5 Hours
- Mount Type: MIL-STD-1913 (Picatinny/Weaver) rail
- Outer shell material: fiber reinforced nylon

Installation

Loosen the mounting screw enough to place the laser on the mounting rail. The recoil slot closest to the trigger guard is usually the most ergonomic location

Charging the Battery

1. Make sure the unit is turned off.
2. Plug the micro-USB end into the laser port.
3. Plug the USB-A end into the wall charger or into a USB port on your computer.
4. When charging begins, the USB charging port displays a red light. When the laser is fully charged, light goes out.

How to Sight Laser

Elevation: Using included hex wrench, turn Elevation screw clockwise to lower beam, counter-clockwise to raise beam.

Windage: Turn Windage screw clockwise to move beam to the left, counter-clockwise to move beam to the right.

